

2G GSM Gateway Voice: Can I enable or disable the call waiting?

Yes,

The Call Waiting service, if supported by the GSM network operator, keeps you informed on a new incoming call during a phone conversation in progress.

ENABLE THE CALL WAITING (*43#)

1. Hook off the phone, you hear the dial tone.
2. Enter the code ***43# to enable the Call Waiting** (using a DTMF phone)
3. If the service is enabled successfully, you will hear the configuration tone (continuous tone repeated twice).
4. Hook on the phone to complete the procedure.

DISABLE THE CALL WAITING (*43#)

1. Hook off the phone, you hear the dial tone.
2. Enter the code **#43# to disable the Call Waiting** (using a DTMF phone)
3. If the service is disabled successfully, you will hear the configuration tone (continuous tone repeated twice).
4. Hook on the phone to complete the procedure.

CHECK THE CALL WAITING STATUS SERVICE (*#43#)

1. Hook off the phone, you hear the dial tone.
2. Enter the code ***#43# to check the Call Waiting status service** (using a DTMF phone)
3. If the service is enabled, you will hear a continuous tone repeated twice.
4. If the service is disabled, you will hear a single continuous tone of few seconds.
5. Hook on the phone to complete the procedure