



Wireless 3G Gateway

HSDPA & HSUPA Station

- Fast Internet **with 7.2 Mbps UMTS Technology**
- Simultaneous **Internet and Voice call**
- Send and Receive **SMS**
- Built-in **ADSL 2/2+** Router function (optional)



3G Gateway Series

User's Guide

rev. 3.0 04/2010

2 Mbps Upload transmission

INDEX

Restriction of use of Wireless Radio Equipment using the 2.4GHz ISM frequency band	II
PREFACE	III
DECLARATION CE OF CONFORMITY	III
SAFETY WARNINGS	IV
1. INTRODUCTION.....	1.1
1.1. DESCRIPTION	1.1
1.2. CONNECTORS PANEL.....	1.2
1.2.1. 3G SOHO CONNECTORS.....	1.2
1.2.2. 3G SOHO PLUS CONNECTORS.....	1.2
1.2.3. 3G BACKUP CONNECTORS.....	1.3
1.2.4. 3G CORPORATE CONNECTORS.....	1.3
1.2.5. 3G WLL CONNECTORS.....	1.3
1.2.6. 3G INDUSTRIAL CONNECTORS.....	1.3
1.3. DISPLAY	1.4
1.4. LED.....	1.5
1.5. PARTS CHECK	1.5
2. HARDWARE INSTALLATION	2.1
2.1. BATTERY BACKUP.....	2.3
2.1.1. REPLACEMENT OF BATTERY.....	2.3
2.2. PIN AND PUK MANAGEMENT	2.4
3. WEB CONFIGURATION.....	3.1
3.1. QUICK CONFIGURATION	3.2
3.1.1. PHONE CALL	3.2
3.1.2. 3G DATA CALL.....	3.2
4. HOME.....	4.1
5. CONFIGURATION	5.1
5.1. LAN.....	5.1
5.1.1. ETHERNET	5.1
5.1.2. WIRELESS NETWORK.....	5.2
5.1.3. DHCP SERVER.....	5.7
5.2. WAN	5.8
5.2.1. WAN CONFIGURATION.....	5.9
5.2.2. ADSL CONFIGURATION	5.10
5.2.3. 3G CONFIGURATION	5.14
5.2.3.1. Remote Activation	5.14
5.2.4. DNS	5.17
5.3. VOICE CONFIGURATION.....	5.18
5.3.1. VOICE CONFIGURATION	5.18
5.3.1.1. Mobile Extension – Mex Application	5.18
5.3.1.2. FXO calls route to.....	5.20
5.3.2. FXS.....	5.20
5.3.3. FXO.....	5.21
5.3.4. UMTS.....	5.22
5.3.5. FXS ROUTING TABLE.....	5.22
5.3.6. UMTS ROUTING TABLE.....	5.24
5.3.7. FXO ROUTING TABLE	5.24
5.3.8. SUPPLEMENTARY SERVICES.....	5.26
5.4. SYSTEM.....	5.27
5.4.1. FIRMWARE UPGRADE.....	5.27
5.4.2. BACKUP & RESTORE.....	5.28
5.4.3. COMMIT & REBOOT.....	5.28
5.4.4. USER MANAGEMENT	5.29
5.4.5. TIME ZONE	5.29
5.5. ADVANCED	5.30
5.5.1. IGMP PROXY	5.30
5.5.2. IP ROUTING.....	5.31
5.5.3. DYNAMIC DNS.....	5.32



5.5.4.	UPNP.....	5.33
5.5.5.	REMOTE CONFIGURATION	5.33
5.5.6.	HALF BRIDGE.....	5.34
5.5.7.	AUTO PING	5.34
5.6.	FIREWALL.....	5.35
5.6.1.	IP FILTERING	5.35
5.6.2.	DOMAIN FILTERING	5.36
5.6.3.	INTRUSION DETECTION	5.36
5.7.	VIRTUAL SERVER.....	5.37
5.7.1.	VIRTUAL SERVER	5.37
5.7.2.	DMZ.....	5.37
5.8.	SMS.....	5.38
5.9.	SECURITY.....	5.38
5.9.1.	BACKUP	5.38
5.9.2.	IN OUT.....	5.38
5.9.3.	E-MAIL.....	5.40
5.9.4.	DISCONNECT TIMEOUT	5.40
6.	SAVE & REBOOT.....	6.1
7.	LOGOUT	7.1

RESTRICTION OF USE OF WIRELESS RADIO EQUIPMENT USING THE 2.4GHZ ISM FREQUENCY BAND

This equipment complies with european standards in matter of electromagnetic compatibility, interference and safety. This equipment operates in the 2.4GHz Wireless radio bandwidth, regulated by the European 1999/5/CE Directive. It can be freely used in those countries which are not specifically applying restrictions.

Restrictions of use in France

Indoor

- The maximum transmit power (EIRP) is limited to 100mW (20 dBm) within the 2400-2483,5MHz frequency range

Outdoor

- The maximum transmit power (EIRP) is limited to 100mW (20 dBm) within the 2400-2454MHz frequency range
- The maximum transmit power (EIRP) is limited to 10mW (10 dBm) within the 2454-2483,5MHz frequency range

Please check www.art-telecom.fr for updates and further informations.

Restrictions of use in France

This equipment can be used freely within private areas.

Should the equipment being used in public areas or outside private areas, the user must apply a general authorization and inform the national telecommunication organization. Please refer to www.comunicazioni.it for updates and further informations.

If the equipment allows to modify the transmit power level or change of the antenna type, the user must ensure not to exceed the 100mW (20 dBm) limit in any case or final setup.



All rights reserved; no part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, otherwise, without the prior written permission of Digicom S.p.A. The contents of this booklet may be modified without notice. Every possible care has been taken in testing and putting together all the documentation contained in this booklet, however Digicom can not take any responsibility brought by the use of this booklet.

PREFACE

In order to guarantee your safety and a correct functioning, be sure to follow these safety warnings. The whole set (with cables included) must be installed in a place lacking of or distant from:

- Dust, humidity, high temperatures and direct exposure to sunlight.
- Heat irradiating objects, which may damage your device or cause any other problem.
- Objects producing a high electromagnetic field (Hi-Fi speakers, etc.).
- Corrosive liquids or chemical substances.

ENVIRONMENTAL CONDITIONS

Environment temperature: from 0 °C to +40 °C Relative humidity: from 20 to 80 % n.c.

Any sudden change in temperature and humidity must be avoided.

CLEANING INFORMATION

Use a soft dry cloth and avoid any solvents or abrasive materials.

SHOCKS OR VIBRATIONS

Caution against shocks or vibrations.

BACKUP BATTERY (OPTIONAL)

WARNING: this device can be supplied with a backup battery.

This battery may get burnt, explode or cause serious burnings. DO NOT disassemble, weld, burn or throw the battery into water. Keep out of children. Replace only with a same model battery and reserve the operation only to qualified staff. The use of a different battery may cause fire hazard or explosions. Italian laws consider batteries as dangerous urban waste that must be disposed according to the law provisions in force (Italian DPR 915/82 and local provisions).

The backup battery is excluded from warranty.

DECLARATION OF CONFORMITY

We, Digicom S.p.A., with registered office at Cardano al Campo (VA - Italy) - Via Volta 39, declare under our sole responsibility, that the products named **3G SoHo, 3G SoHo PLUS, 3G BackUP, 3G Corporare, 3G WLL**, to which this declaration refers to, satisfy the essential requirements of following Directive:

- 1999/5/CE 9th March 1999, R&TTE (concerning radio equipment and telecommunication terminal equipment and the acknowledgment of their conformity) Law Decree 9th May 2001, n.269, (G.U. n. 156 of 7-7-2001).

As indicated in conformity with the requirements of following Reference Standards or of other regulations documents:

EN 300 328	EN 301 489-1	EN 301 489-7	EN 301 489-24
EN 301-908-1	EN 301-908-2	EN 60950-1	

We, Digicom S.p.A., with registered office at Cardano al Campo (VA - Italy) - Via Volta 39, declare under our sole responsibility, that the products named **3G Industrial** to which this declaration refers to, satisfy the essential requirements of following Directive:

- 1999/5/CE 9th March 1999, R&TTE (concerning radio equipment and telecommunication terminal equipment and the acknowledgment of their conformity) Law Decree 9th May 2001, n.269, (G.U. n. 156 of 7-7-2001).

As indicated in conformity with the requirements of following Reference Standards or of other regulations documents:

EN 301 489-1	EN 301 489-7	EN 55022
EN 55024	EN 301 511	EN 60950-1

This device can be used in the following countries: IT, DE, ES, PT, BE, NL, GB, IE, DK, GR, CH

ASSISTANCE AND CONTACTS

Most of questions can be answered by looking up in the Support > F.A.Q. section of our website at www.digicom.it. If you can't find the answer you're looking for, please contact our Technical Support at support@digicom.it

SAFETY WARNINGS

Read these instructions and norms carefully before powering the 3G Gateway. Violation of such norms may be illegal and cause hazard situations.

For any of the described situations please refer to the specific instructions and norms.

The 3G Gateway is a low power radio transmitter and receiver. When it is ON, it sends and receives radio frequency (RF) signals.

The 3G Gateway produces magnetic fields. Do not place it next to magnetic supports such as floppy disks, tapes, etc.

Operating your 3G Gateway close to other electrical and electronic equipment - such as a television, phone, radio or a personal computer - may cause interferences.

INTERFERENCES



The 3G Gateway, like all other wireless devices, is subject to interferences that may reduce its performances.



ROAD SAFETY

Do not use your 3G Gateway while driving. In case of use on cars, you must check that the electronic equipment is shielded against RF signals. Do not place the 3G Gateway in the air bag deployment area.



AIRCRAFT SAFETY

Switch off your 3G Gateway when on board aircrafts by disconnecting the power supply and deactivating the internal backup battery. Using GSM devices on aircrafts is illegal.



HOSPITAL SAFETY

Do not use the 3G Gateway near health equipment, especially pacemakers and hearing aids, in order to avoid potential interferences. Take care when utilizing the 3G Gateway inside hospitals and medical centres, which make use of equipment that could be sensitive to external RF signals. Switch it off when use is expressly forbidden.



EXPLOSIVE MATERIALS

Do not use the 3G Gateway in refuelling points, near fuel or chemicals. Do not use the 3G Gateway where blasting is in progress. Observe restrictions and follow any specific regulation or instruction.



INSTRUCTIONS FOR USE

Do not use the 3G Gateway in direct contact with the human body and do not touch the antenna if not strictly necessary.

Use approved accessories only. Consult documentation regarding any possible device connected to the 3G Gateway. Do not connect incompatible products.

INFORMATION FOR USERS



According to the 2002/95/CE, 2002/96/CE and 2003/108/CE Directives, relative to reduction in the use of hazardous substances in electrical and electronic apparatus, as well as to disposal of waste materials.

The symbol of a crossed box applied on the apparatus or on its package indicates that at the end of its useful life the product must be collected separately from other waste materials.

The user must therefore take the apparatus which has reached the end of its useful life to appropriate separate collection centres for electronic and electro-technical waste materials, or deliver it back to the reseller when purchasing new apparatus of an equivalent type, giving one piece in for one piece out.

Suitable separate waste collection for then sending the cast-off apparatus for recycling, treatment and environmentally friendly disposal, contributes towards preventing any possible negative effects on the environment and on health and encourages recycling of the materials the apparatus is made up of.

Unauthorised disposal of the product by the user will lead to payment of the administrative sanctions in force in the country where it is put on the market.

1. INTRODUCTION

Dear Customer,
thanks for purchasing 3G Gateway.

You will now be able to access the Internet using 3G connection or ADSL connection (optional).

This User's Guide will show you how to connect your 3G Gateway and to customize its configuration to get the most out of your new product.



1.1. DESCRIPTION

3G Gateway identifies a range of Digicom 3G routers:

- 3G SoHo
- 3G SoHo PLUS
- 3G BackUP
- 3G Corporate
- 3G WLL
- 3G Industrial

This user manual describes all the functionalities of 3G Gateway.

The table shows the main differences among 3G Gateway versions:

Functionality	3G Industrial	3G SoHo	3G SoHo PLUS	3G BackUP	3G Corporate	3G WLL
UMTS (HSUPA)	Yes	Yes	Yes	Yes	Yes	Yes
ADSL (2/2+)	No	No	Yes	Yes	Yes	No
1 LAN 10/100	Yes	Yes	Yes	Yes	Yes	Yes
Tel FXS	No	Yes	Yes	No	Yes	Yes
Line FXO	No	No	Yes	No	Yes	No
1 SIM Holder	Yes	Yes	Yes	Yes	Yes	Yes
2 SIM Holder	No	No	No	Optional	Optional	No
In/Out	No	No	No	No	Yes	No
Display	No	Yes	Yes	No	No	No
WiFi	Yes	Yes	Yes	Yes	Yes	Yes
Battery Backup	Optional	Optional	Optional	Optional	Optional	Yes

Housing




Note: As for the Description and Installation of 3G Industrial, please refer to the Quick Guide of the product itself.

This User' Guide is valid for the Configuration only.

1.2. CONNECTORS PANEL

CONNECTOR	DESCRIPTION
A	TEL (1,2) RJ11 FXS connectors for analog phones or PABX trunks (parallel)
B	LAN RJ45 connector for ethernet cable
C	PWR Power supply connector
D	SIM SIM connector. The models supporting double SIM will have 2 SLOTS
E	ADSL RJ11 connector for ADSL line (available on models with ADSL router only)
F	LINE RJ11 FXO connectors for PABX extensions
G	RESET Reset (Power OFF/ON). For Backup battery models, power the device OFF and press it for 10 sec
H	FACTORY Reset to factory default
L	GROUNDING Grounding clamp




1.2.1. 3G SoHo Connectors



1.2.2. 3G SoHo PLUS Connectors



1.2.3. 3G BackUP Connectors




1.2.4. 3G Corporate Connectors



1.2.5. 3G WLL Connectors



1.2.6. 3G Industrial Connectors



Attention: the connector (C) can be different from the one shown in the picture.

1.3. DISPLAY

3G Gateway (SoHo models) is equipped with a 65.000 colors display where you can see the information on the gateway operation status.



SYMBOL		DESCRIPTION
	SMS	It indicates the presence and the numbers of unread SMS in the SIM
	Missed calls	It indicates the presence and the number of missed calls
	Battery Backup	It indicates the Backup battery status (optional)
	ADSL	ADSL connected
	ADSL	ADSL disconnected
	Signal	It indicates the status of GSM signal
	GSM Mode	3G indicates the roaming range of 3G network
A	Operator	Operator where the SIM is registered
B	Connession	It indicates the status of data connection
C	Time & Date	It indicates the time and date
	WiFi	WiFi enabled
	LAN	A computer, switch or other network device is correctly connected to the LAN port

1.4. LED

Depending on the version you buy 3G Gateway Series may have different front panel.

You can verify the device status through the LED on the front panel (no display versions).

LED	STATUS	DESCRIPTION
Power	Off	Device off
	On	Device correctly powered
3G	Off	SIM not ready
	Flashing Green	SIM ready and no 3G data connection on
	On Green	SIM ready and 3G data connection on
	Flashing Red	SIM ready and no 2G data connection on
	On Red	SIM ready and 2G data connection on
	Fast Flashing Red	Insert PIN/PUK
WiFi	Off	WiFi disabled
	On	WiFi enabled
LAN	Off	No device connected on the Ethernet port
	On	Computer, switch or other network device correctly connected to the LAN port
TEL	Off	Line not engaged
	Flashing	Line engaged
LINE	Off	Line not engaged
	Flashing	Line engaged
ADSL	Flashing	ADSL line (physical level) not available
	On	ADSL line (physical level) available



1.5. PARTS CHECK

The package will contain the following items:


- 3G Gateway
- Power adapter
- Quick Guide
- Wi-Fi antenna
- GSM antenna
- Ethernet cable RJ45-RJ45

2. HARDWARE INSTALLATION


2

Just three steps to operate with 3G Gateway:

1. Connect the **GSM antenna** and the **WiFi antenna** (the pictures show two different models).




2. Insert the **SIM** (we recommend to disable the PIN). For a correct operation turn 3G Gateway off.



3. Connect the **power supply** and turn 3G Gateway on.

Now you can connect a phone to the connector Tel 1 and you will be able to make and receive calls. (Function not supported by 3G BackUP).

The next image shows the other connection types:



LAN

To configure 3G Gateway and/or surf the internet, connect the computer through the LAN port. If more than one device must be connected, use an external switch. To use the WiFi, simply enable this option in the configuration web pages.

ADSL

If your 3G Gateway supports the ADSL router, connect the line to the ADSL port.

LINE

If your 3G Gateway supports the FXO interface, connect the PABX extension or public line to the LINE port.

Display & LED


Through the display or the LEDs it is possible to check 3G Gateway status.

2.1. BATTERY BACKUP


The battery backup is placed into the product. The connection of the battery is at the installer or at the end user's care.
Battery backup features: Li-ion 7,4V 1700mAh

To connect the battery backup:

- Power off the device and remove the plastic cover by turning the screws



- Insert the connector into the card as shown in picture



- Close the upper plastic cover and secure it by using the two screws.

2.1.1. Replacement of battery

The battery is stuck on the device.
To replace it, disconnect the connector from the card and gently remove the battery.



Note: You are advised to use battery supplied by Digicom only.

2.2. PIN AND PUK MANAGEMENT

The PIN request is always enabled on the SIMs; to use them inside 3G Gateway you can:

1. Disable the PIN request on the SIM (through a cellular phone).
2. Insert the PIN in the 3G Gateway configuration. At power on, the device will send the PIN to the SIM.

3G Gateway will show the PIN request from the SIM on the display (Insert PIN) or through the fast blinking of 3G led (red) in the versions without display.

You can setup 3G gateway in two ways:

- A. WEB based configuration (3G Umts menu). Click Save&Reboot to enable the configuration.

- B. Through the phone keyboard (set the DTMF selection) connected to TEL1 or TEL2 connector (**available in the version with TEL-FXS port only**).

Lift the receiver, you will hear the tone of PIN code request (two close beeps repeated with a pause).

1. Digit the PIN code using the phone keyboard and confirm by pressing “#” (set on the phone the DTMF selection) PIN# code (i.e.0123#)
2. To cancel the PIN code insertion, hang up before you confirm the PIN code with “#”.
3. If the PIN code is correct, you will hear the correct configuration tone (two tones repeated), or the tone for wrong PIN (three tones repeated).
4. Hang up to complete the procedure. Now 3G Gateway will automatically save the PIN in the configuration and it will **make a Reset**.
5. At 3G Gateway start up, the PIN is no more asked for and the SIM will register to the network.

PUK management

The PUK code can be inserted with the same procedure as for the PIN insertion, through the phone keyboard (available in the version with TEL-FXS port only) or by inserting the SIM inside a mobile phone.



ATTENTION: the PIN and PUK codes are indicated on the PIN-PUK card supplied by the Telecom Operator when you buy the SIM card. If a wrong PIN number is inserted for 3 times, it will be necessary to insert the PUK code followed by a new PIN code. After 10 wrong PUK codes, the SIM card will be blocked permanently and you have to substitute it.

3. WEB CONFIGURATION

3

Getting Started with the Web pages

3G Gateway includes a series of Web pages that provide an interface to the software installed on the device. It allows you to configure the device settings to meet the needs of your network. You can access it through a web browser on a PC connected to the device.

Accessing the Web pages

To access the web pages, you need the following:

- A laptop or PC connected to the LAN port on the device.

To enter the configuration menu you must set on the computer an IP address of the same LAN of 3G Gateway; you can set the address statically or using the assignment through the DHCP Server.

Windows® XP

- From the **Start** menu select -> **Control Panel** -> **Network connections**.
- Select **LAN Connection**, display the **Properties**, select **Internet Protocol (TCP/IP)** and press on **Properties** button.

☐ Ottieni automaticamente un indirizzo IP
☒ Utilizza il seguente indirizzo IP:


Indirizzo IP:	192 . 168 . 1 . 119
Subnet mask:	255 . 255 . 255 . 0
Gateway predefinito:	192 . 168 . 1 . 254

- If using a DHCP Server, set **Obtain automatically an IP Address**, 3G Gateway will appropriately configure the IP addresses.
- A web browser installed on the PC. For the best display quality, use latest version of Internet Explorer, Netscape or Mozilla Firefox. from any of the LAN computers, launch your web browser, type the following URL in the web address (or location) box, and press **Enter** on your keyboard:

http://192.168.1.254 (user: admin, pwd: admin)

The web pages for the configuration have a column on the left, where you find the configuration menus, and a central part where you can see the settings and modify them.

The main menus are the following: Home, Configuration, Save & Reboot and Logout.



3.1. QUICK CONFIGURATION

This paragraph describes the main parameters to be set to make and receive calls (if the FXS “TEL” interface is supported) and to start the Internet surfing in 3G mode.

3.1.1. Phone Call




For FxS interface versions only.

To start making/receiving calls you must have followed the instructions of the Hardware Installation chapter:

- Connect the GSM antenna
- Insert the SIM (we recommend to disable the PIN)
- Connect a phone to the connector Tel 1
- Connect the power supply and turn 3G Gateway on
- As soon as the display (or 3G led) will show the operator name, you will be able to make and receive calls.

3.1.2. 3G Data Call

To make a call in 3G mode, check that the WAN is set to 3G (Configuration menu, WAN, WAN configuration).



- In the **3G UMTS** menu insert the information (depending on the GSM operator you are using) for APN, Username and Password (for some operators the APN is sufficient).

- Define the connection mode:

Always on: 3G Gateway will enable 3G connection at power on. If some disconnections should occur, the Gateway will try to restore them automatically.

Manually: In this mode the user manually decides when the connection must be enabled and for how long. To enable (connect) and disable (disconnect) 3G connection, use the push buttons in the Home page.



Note: Verify with your telecom operator the profile of the SIM you are using for the Internet connection.

3G Configuration

Advanced 3G Configuration

Connection	Manually ▾
SMS service centre	<input type="text"/>
Apn	ibox.tim.it
Username	<input type="text"/>
Password	<input type="text"/>
Pin	<input type="text"/>
Idle timeout	20
Obtain DNS automatically	<input checked="" type="checkbox"/>

Apply

- **Save** the configuration and reboot the gateway (menu Save & Reboot).

Commit & Reboot

Save Configuration & Reboot Page

This page allows you to save configuration to flash to retain configuration across reboots. You can also use this page to reboot modem with the configuration file you wanted, simply select the configuration file and press reboot

Commit Configuration

Use to save current Router's configuration to flash

Commit

Reboot Router

Use to Reboot Router with the listed configuration files

Reboot From

Last ▾

Reboot

- If the ethernet card of the computer connected to 3G Gateway is set to DHCP mode, 3G Gateway will appropriately configure the IP addresses and you will be able to start surfing.
- If the ethernet card is configured with static IP addresses, check that the preset Gateway address is the one of 3G Gateway.

☐ Ottieni automaticamente un indirizzo IP

☒ Utilizza il seguente indirizzo IP:


Indirizzo IP:	192 . 168 . 1 . 119
Subnet mask:	255 . 255 . 255 . 0
Gateway predefinito:	192 . 168 . 1 . 254

4. HOME

- The Home menu has various options that allow to verify the device status.



- The Home and Status pages display the device overview:



Status

Device Information


Model Name	3G Gateway
Host Name	MyModem
System Up-Time	00:17:24s
Current Time	Synchronize Client with NTP Server now! <input type="button" value="Synchronize"/>
Hardware Version	Solos 4615 RD / Solos 461x CSP v1.0
Software Version	10.0.3.23
MAC Address	00:A0:A2:55:55:05
Home URL	digicom s.p.a

LAN


IP Address	192.168.2.1
Subnet Mask	255.255.255.0
DHCP Server	On
WAN	

5. CONFIGURATION

The **Configuration** menu has various options for the device configuration.



5.1. LAN



5.1.1. Ethernet

Home

Configuration

Lan

Ethernet

Wireless Network

Wireless Client Filter

DHCP Server

Wan

Voice Configuration

System

Advanced

Firewall

Virtual Server

SMS

Save & Reboot

Logout

Local Network Configuration

LAN side IP Address Settings

Primary IP Address

Enter here the IP address of your Router. This is the address visible from the computers on your network.

IP Address:

192.168.3.219

Subnet Mask:

255.255.252.0

Host Name:

MyModem

Domain Name:

local.lan

Virtual IP Address

☐ Configure Virtual IP address and subnet mask

IP Address:

Subnet Mask:

MTU

1500 (default: 1500)

New settings only take effect after your Router is rebooted. If necessary, reconfigure your PC's IP address to match new settings.

This page displays the local network configuration where you can configure:

- IP Address: (Enter the Primary IP Address. For example, enter 192.168.1.1)
- Subnet Mask: (Enter the Subnet Mask. For example, enter 255.255.255.0)
- Host Name
- Domain Name
- Virtual IP Address: (Select the check box, "Configure Virtual IP address and subnet mask" to specify the Virtual IP Address and Subnet Mask)
- MTU (Enter the value of MTU. 1500 is the default value)

5.1.2. Wireless Network

This page allows you to setup the wireless connection. The following settings are allowed:

- Basic
- Advanced
- WDS Settings
- MAC Address Filter
- Radius Server

Basic Settings

Global Setting

Wireless Network

[Basic Settings](#) | [Advanced Settings](#) | [WDS Settings](#) | [MAC Address Filter](#) | [Radius Server](#)

To make sure MyDslModem does not transmit on illegal frequencies, you must set where you are in the world.

Global Setting

Select Profile: 802.11B/G

Wireless Network: ☐ Disable ☒ Enable

Select Country: Italy

You may either choose a channel yourself, or allow to automatically select the best channel.

Channel Selection: Auto

Select Channel: 2

Network Name (SSID): gateway

Hide SSID: ☒ No ☐ Yes

- Select Profile:** Select one of the following profiles: 802.11 B/G, 802.11 B Only, 802.11 G Only, 802.11 MIXED_LONG, 802.11 A. If you do not know or have both 11g and 11b devices in your network, then keep the default in 802.11 B/G.
- Wireless Network:** Select the option Enable or Disable
- Select Country:**
- Channel Selection:** Select the channel as Auto or Manual.
- Network Name (SSID):** The ESSID is the unique name of a wireless access point (AP) to be distinguished from another. Make sure your wireless clients have exactly the ESSID as the device, in order to get connected to your network.
- Hide SSID:** You may choose to Hide SSID (Yes/No). This function transmits its ESSID to the air so that when the wireless client searches for a network, the router can then be discovered and recognized.

Security Settings

You can disable or enable with WPA or WEP for protecting the wireless network.

Security Settings	
Select Security Option:	Off - No Encryption ▾
WEP Authentication Mode:	<input checked="" type="radio"/> Open <input type="radio"/> Shared
Select Tx Key Index:	0 ▾
Select Key Method:	Pass Phrase ▾
Key:	<input type="text"/>
WEP Pass Phrase:	<input type="text"/>
Select Encryption Protocol:	TKIP protocol ▾
Select Authentication Method:	PSK (Pre Shared Key) ▾
WPA Pass Phrase:	00000000000000000000000000000000
802.1x Identity String:	3G Full 00:11:22:33:44:66
802.1x Rekey Timeout:	600

Select Security Option: Select the security option from the drop down list.

The available security options are: Off – No Encryption, 64 Bit Encryption, 128 Bit Encryption, Wi-Fi Protected Access, Wi-Fi Protected Access 2, and WPA Mixed Mode. Click Confirm

WEP Encryption:

To prevent unauthorized wireless stations from accessing data transmitted over the network, the router offers highly secure data encryption, known as WEP. If you require high security for transmissions, there are two alternatives to select from: WEP 64 (64 Bit Encryption) and WEP 128 (128 Bit Encryption) . WEP 128 will offer increased security over WEP 64.

Select Key Method:

With Pass Phrase you will insert a WEP Pass Phrase and with Direct Key you will insert a Key.

WEP Pass Phrase:

This is used to generate WEP keys automatically based on the input string and a pre-defined algorithm in WEP64 or WEP128.

Key:

Enter the key to encrypt wireless data. To allow encrypted data transmission, the WEP Encryption Key values on all wireless stations must be the same as the router. There are four keys for your selection. The input format is in HEX style, 10 and 26 HEX codes are required for WEP64 and WEP128 respectively.

WPA (Wi-Fi Protected Access): There are two types of the WPA-PSK and WPA2-PSK.

WPA Pass Phrase:

The key for network authentication. The input format is in character style and key size should be in the range between 8 and 63 characters.

Advanced Settings

Wireless Network

[Basic Settings](#) | **[Advanced Settings](#)** | [WDS Settings](#) | [MAC Address Filter](#) | [Radius Server](#)

To make sure MyDslModem does not transmit on illegal frequencies, you must set where you are in the world.

Global Setting

Select Profile:	802.11B/G
Wireless Network:	<input type="radio"/> Disable <input checked="" type="radio"/> Enable
Select Country:	Italy
You may either choose a channel yourself, or allow to automatically select the best channel.	
Channel Selection:	Auto
Select Channel:	2
Network Name (SSID):	gateway
Hide SSID:	<input checked="" type="radio"/> No <input type="radio"/> Yes
Fragmentation Threshold :	2346
RTS Threshold :	2347
NitroXM PiggyBack:	<input type="radio"/> Disable <input checked="" type="radio"/> Enable
WMM:	<input checked="" type="radio"/> Disable <input type="radio"/> Enable

In addition to the settings provided under basic settings, you can specify: Fragmentation Threshold, RTS Threshold, NitroXM PiggyBack, and WMM.

WDS Settings

Wireless Distribution System is a wireless access point mode that enables wireless link and communication with other access point. Easy to install simply defining peer's MAC address of the connected AP.

WDS Configuration

[Basic Settings](#) | [Advanced Settings](#) | **[WDS Settings](#)** | [MAC Address Filter](#) | [Radius Server](#)

Wireless channel must be same for each AP and configured manually from [Global Settings](#) page for WDS connectivity.

WDS Port	MAC- Address
----------	--------------

- ☒ Disabled - Different Access Point will not be able to communicate.
- ☐ Enabled - Different Access Point will be able to communicate.

Apply

WDS Port Setting

Select WDS port :

WDS MAC Address

Enter MAC Address : : : : : :

Confirm

MAC Address Filter

Wireless Network

[Basic Settings](#) | [Advanced Settings](#) | [WDS Settings](#) | **MAC Address Filter** | [Radius Server](#)

You can restrict which wireless PCs can connect to your device. Select how you want to restrict PCs below.

Select MAC Auth

Disabled ▾

MAC Address

Delete

Add MAC Address:

Apply

You can specify which wireless PCs can connect to your device.

- Select MacAuth
- You can select which MAC authorization option as Disable, White List or Black List.
- Add MAC Address
- Enter the MAC address and click Apply. You can also delete the existing MAC address by clicking Delete.

Radius Server

Wireless Configuration

[Basic Settings](#) | [Advanced Settings](#) | [WDS Settings](#) | [MAC Address Filter](#) | **Radius Server**

Radius Server Configuration

Radius Server Status: ☒ Enable ☐ Disable

Apply

Authentication Server

Id	Name	IP Address	UDP Port	Retries	Timeout	VAP port	Edit	Delete
----	------	------------	----------	---------	---------	----------	------	--------

Add

Accounting Server

Id	Name	IP Address	UDP Port	Retries	Timeout	VAP port	Edit	Delete
----	------	------------	----------	---------	---------	----------	------	--------

Add

Radius server configuration is required when user configures the wireless network for Radius Authentication (802.1x EAP) for WPA/WPA2 security.

It allows user to configure different accounting and authentication servers or to configure the same server for both authentication and accounting. It allows you to configure (Name, IP Address, UDP Port, Retries, Timeout) settings for the Radius server.

Click Add to add the Authentication Server:

Radius Server

Radius Server Configuration

Name

IP Address

Shared Key

UDP Port

Retries

Timeout

VAP Port

times

seconds

wireless ☒ Add ☐ Delete

Submit

Cancel

To enable/disable the radius server: Select Enable or Disable and click Apply.

To set the authentication server:

- Click Add.
- Enter the Name, IP Address, Shared Key, UDP Port, Retries (connection retry time), Timeout, and VAP Port details.
- Click Submit.

To set the accounting server:

Enter the details as described above and click Submit.

5.1.3. DHCP Server

Global Settings: to enable/disable the DHCP server: Select Enable or Disable and click **Apply**.
In this page you can configure DHCP Relay functionality.

DHCP Server Configuration
[Global Settings](#) | [Server Settings](#) | [Fixed Host Settings](#) | [Ip range Settings](#)

DHCP Server Configuration
This page allows you enable and disable the DHCP server. Also you can specify the interfaces that DHCP Server will operate on.

DHCP server status
DHCP server is currently

☒ Enable ☐ Disable

DHCP Relay status
DHCP Relay is currently
DHCP Relay Server address

☐ Enable ☒ Disable
0.0.0.0

Apply

Server Settings: you can configure the DHCP server options assigned to the clients.

DHCP Server Configuration
[Global Settings](#) | [Server Settings](#) | [Fixed Host Settings](#)

Add DHCP server subnet
This page allows you to set up a new DHCP server subnet so that the system can assign IP address, subnet mask and option configuration parameters to DHCP clients. The DHCP Server must be enabled to add a subnet to it.

Parameters for this subnet
Define your new DHCP subnet here. If you do not wish to specify the subnet value and subnet mask by hand, you may instead select an IP interface using the Get subnet from IP interface field. A suitable subnet will be created based on the IP address and subnet mask belonging to the chosen IP interface.

Subnet value
Subnet mask
Maximum lease time
Default lease time

192.168.0.0
255.255.252.0
86400
43200

Seconds
Seconds

DNS server option information
You may allow DHCP server to specify its own IP address by clicking on the Use local host address as DNS server checkbox.

Use local host address as DNS server ☒

Default gateway option information
Use local host as default gateway

☒

Apply Cancel

Fixed Host Settings: Select Add Fixed Host and insert IP address and MAC Address.
The MAC address should be expressed as 6 hexadecimal pairs separated by colons, e.g. 00:20:2b:01:02:03

DHCP Server Configuration
[Global Settings](#) | [Server Settings](#) | [Fixed Host Settings](#)

DHCP Server Configuration
This page allows creation of DHCP server fixed host IP/MAC mappings.

Existing DHCP fixed IP/MAC mappings

IP Address	Mac Address	Max Lease Time	Default Lease Time	Edit	Delete
------------	-------------	----------------	--------------------	------	--------

Add Fixed Host

digicom

5.7

Ip range Settings: you can configure the IP range assigned to the clients. If you need change the default rule, you must delete the rule present in the web page and insert a new one.

DHCP Server Configuration
[Global Settings](#) | [Server Settings](#) | [Fixed Host Settings](#) | **[Ip range Settings](#)**

DHCP server subnet ip ranges

You need to make sure that the start and end addresses offered in this range are within the subnet. DHCP Server must be enabled to add an iprange to the subnet.

Start Ip	End Ip	Delete
192.168.1.1	192.168.1.21	

Create new subnet ip range

You need to make sure that the start and end addresses offered in this range are within the subnet.

Start Ip


End Ip

Apply

Cancel

5.2. WAN

The WAN menu has the following WAN options: WAN Configuration, ADSL Configuration, 3G UMTS e DNS.



5.2.1. WAN Configuration

3G Gateway can manage 2 different WAN types: 3G (HSDPA/HSUPA module) and ADSL (optional, not present on all models). The two interfaces will operate alternatively, not simultaneously. The device can be set to operate in 3 modes:

1. 3G mode only
2. ADSL mode only
3. ADSL + back-up over 3G
4. 3G + back-up ADSL



Note: Point 2 and 3 for ADSL interface versions only.

Wan

Selected Wan Interface

To enable 'ADSL+BackUP 3G' or '3G+BackUP ADSL' configuration you must set an ADSL interface.

BackUP

Manual ☒ Automatically ☐

To operate "Automatically", the 3G and ADSL configurations must be set in 'always on' mode.

BackUP rules

ADSL down/3GPPP down ☒ No ping ☐ Default Gateway ☐ Host

BackUP timeout (sec) Restore timeout (sec)

3G

3G

ADSL

ADSL+BackUP 3G

3G+BackUP ADSL

If you select ADSL + BackUP you will be able to set the backup options in the BackUP section.

Backup and Restore can be manually or automatically set.

With the **manual backUP** you will enable the connection through the **Connect** and **Disconnect** buttons in the Home Page. If the user has connection problems (the information will be displayed) he can manually enable the UMTS connection. An eventual Connect for the UMTS connection automatically disconnects the ADSL. If the user disconnects the UMTS connection, 3G Gateway will try to connect through the ADSL line.

Automatic backup

With this setup 3G Gateway automatically pass from ADSL to UMTS (Backup) connection according to the configuration of BackUP rule menu.

- **No Ping:** the backup/restore occurs only after the status (physical level) of ADSL line has been checked.
- **Default Gateway:** besides the physical level of ADSL line, also a check (PING) of default Gateway is carried out. In this mode the BackUP is carried out even in case the ping with ADSL UP line fails. It is important to check that normally the Default Gateway answers the PING.
- **Host:** In this mode, besides the physical level of ADSL line, it is carried out also a check (PING) of two addresses that the user can insert. In this mode the BackUP is carried out even in case that with ADSL UP line the ping to both inserted addresses fails. It is important to check that normally the two inserted addresses answer the PING.

The backup or the following restore will be carried out if one of the above mentioned cases occurs for a time longer than the one defined in backup timeout or restore timeout (default 90 seconds).

5.2.2. ADSL Configuration



For ADSL interface versions only.

You can configure your internet connection from this page. This page displays the details of existing internet connection, if any. You can perform the following functions from this page:

- Connection
- Configure ADSL
- Specify MAC Spoofing

Internet connection configuration

Internet Connection Configuration

Connections | [ADSL](#) | [MAC Spoofing](#)

Internet Connection Configuration

Choose Add to add a Internet connection. Click Delete to delete an existing Internet connection.

PVC Name	VPI/VCI	Category	Protocol	NAT	WAN IP Address	Edit	Delete
PpoeUp Connect ✕	0/100	UBR	PPPoE LcBridged	On	Not Assigned		
Rfc1483Up	0/101	UBR	RFC1483-Routed VcMuxRouted	*	*		

Add >

Connections

- To configure the internet connection: Click Add. Follow the steps described to setup the internet connection.
- To edit the internet connection: Click Edit. Configure ATM PVC page opens:

Internet Connection Configuration

Configure ATM PVC

Please enter VPI and VCI numbers for the Internet connection which is provided by your ISP.

VPI: (0-255)

VCI: (32-65535)

Service Category: ▾

Peak Cell Rate: cell/s(1-7100)

Sustainable Cell Rate: cell/s(1-7099)

Maximum Burst Size: cells(1-1000000)

Next > Cancel

- Configure ATM PVC page opens:

Internet Connection Configuration

Configure ATM PVC

Please enter PVC Name, VPI and VCI numbers for the Internet connection which is provided by your ISP.

PVC Name:

VPI: (0-255)

VCI: (32-65535)

To configure ATM PVC:

- Enter the name of PVC in PVC Name.
- Configure the ATM PVC by entering the VPI and VCI values provided by the ISP.
- Click Next. Configuring Connection Type page opens.

Internet Connection Configuration

Configure Connection Type

Select the protocol and encapsulation type with the ATM PVC that your ISP has instructed you to use.

Protocol:

☐ PPP over ATM (PPPoA)

☒ PPP over Ethernet (PPPoE)

☐ IP over ATM (IPoA)

☐ RFC1483(Routed)

☐ Bridging

Encapsulation Type:

Encapsulation Mode:

To configure the connection type:

- Select the Protocol by selecting the radio button for the desired protocol type.
- Select the Encapsulation Type from the drop down list.
- Select the desired Encapsulation Mode from the drop down list. Configuring WAN IP Settings page opens.

Configure WAN IP Settings

Enter information provided by your ISP to configure the WAN IP settings.

☐ Enable/Disable the Access Concentrator option

Access Concentrator:

☒ Obtain an IP address automatically

☐ Use the following IP address:

WAN IP Address:

☐ Enable NAT

☐ Add Default Route

To configure the WAN IP settings:

- Select/Unselect to enable or disable the Access Configurator option. In case you enable the access configurator, enter the value in Access Concentrator.
- Select one of the following options:
- Obtain an IP address automatically.
- Use the following IP address: specify the WAN IP Address.
- Click to Enable NAT.
- Click to Add Default Route.
- Click Next.

Internet Connection Configuration**Configure Broadband User Name and Password**

To use your Broadband service, please verify your Broadband user name and password.

Broadband User Name:

Password:

Confirm Password:

Session established by:

☒ Always On

☐ Dial on Demand

☐ Consider Lanside Traffic Only

Disconnect if no activity for minutes

☐ Manually Connect

☐ Consider Lanside Traffic Only

Disconnect if no activity for minutes

To configure the broadband user name and password:

- Enter the user name in Broadband User Name.
- Enter the password in the Password field and confirm it by entering it again in the Confirm Password field.
- Specify the network session by selecting Always On, Dial on Demand or Manually Connect option. You can also choose to disconnect after a specified period when no user activity is detected. Also, you can specify "Consider Lanside Traffic Only". By default, the option Always On is selected.
- Click Next.

ADSL Configuration

You can configure your ADSL Attributes in this page.

[Connections](#) | [ADSL](#) | [MAC Spoofing](#)

ADSL Supported Annexes

This page lists various ADSL supported capabilities. Capabilities can be configured by selecting checkboxes.

Common Settings

[Basic Attributes](#)

Annex Specific Settings

Capability

☒ AnnexA

[AnnexA Attributes](#)

☒ T1413A

☒ A2Plus

[BisA Attributes](#)

☒ A2

☒ M2Plus

[BisM Attributes](#)

☒ M2

[Apply](#)

[Start](#)

[Defaults](#)

MAC Spoofing

Internet Connection Configuration

[Connections](#) | [ADSL](#) | [MAC Spoofing](#)

MAC spoofing lets MyModem identify itself as another computer or device. You may need to use this depending on your Internet Service Provider.

Select whether you need MAC spoofing enabled from the options below:

☒ Disabled - MAC Spoofing is not used

☐ Enabled - MAC Spoofing will be used with a MAC address you provide

[Next](#)

[Cancel](#)

- MAC spoofing lets the MyDslModem identify itself as another computer or device. You may need to use this depending on your Internet Service Provider.
- To specify MAC Spoofing:
- Select either Disabled - MAC Spoofing is not used or Enabled - MAC Spoofing will be used with a MAC address you provide. MAC Spoofing Setup/Confirm page opens based on the option previously selected.
- Specify the MAC address in case you enabled the MAC Spoofing.
- Click Next to confirm the specified MAC Spoofing settings.

5.2.3. 3G Configuration

3G Configuration

[Advanced 3G Configuration](#)

Network mode	Automatic ▾	
Connection	Always on ▾	
SMS service centre	<input type="text"/>	
APN	ibox.tim.it	
Username	<input type="text"/>	
Password	<input type="text"/>	
PIN	<input type="text"/>	

Remote Activation ☐
Code
Delete all SMS ☐
CLI activation ☐
SMS Answer ☐

Anyone ☐
Disconnect timeout
Phone Num.1

Phone Num.

Phone Num.2

Network mode: You can configure the network selection in: Automatically, GSM only, 3G Only or 3G preferred.

Define the connection mode:

- **Always on:** 3G Gateway will enable 3G connection at power on. If some disconnections should occur, the Gateway will try to restore them automatically.
- **Manually:** In this mode the user manually decides when the connection must be enabled and for how long. To enable (connect) and disable (disconnect) 3G connection, use the push buttons in the Home page. With manually connection you can configure the remote activation with SMS or CLI.

SMS service center: Number of SMS service center

APN, Username e Password: These information depend on operator that must supply them.

PIN: If the SIM you are using requires the PIN, you must insert it in this field.

Idle Timeout: not supported, for future application.

5.2.3.1. Remote Activation

To enable Remote Activation (RA) it is necessary to activate the functionality and set the options in 3G UMTS menu.

Remote Activation ☐
Code
Delete all SMS ☐
CLI activation ☐
SMS Answer ☐

Anyone ☐
Disconnect timeout
Phone Num.1

Phone Num.

Phone Num.2

Code: 4 digits code set by user.

Anyone: If ON any mobile phone can enable the remote connection with an SMS.

Phone Num: This allows the restriction of enabling remote connection to one number only. The number must be inserted with the international prefix (i.e., +393351234567). Only the number inserted in Phone Num will be able to activate the remote connection (Anyone option disabled).

Delete all SMS: If enabled, it activates the cancellation of all SMS received after the reception of an SMS concerning the RA application (connection, disconnection and reset). This option is useful in installations without operator to avoid the SIM fills with SMS, blocking the operation of Remote Activation.

- Disconnect Timeout:** It defines the period of connection (default 600 seconds). After the disconnect timeout the connection is cut down. It is possible to set an high disconnection time and remotely interrupt the connection via WEB (disconnect button) or via SMS (code disconnect)
- CLI activation:** Possibility to remote enable the connection through the Caller ID. Available only if the SIM supports voice calls.
- Phone Num.1-2:** Insert 2 phone numbers authorized to remote enable the call (CLI). The numbers must be inserted with the international prefix (i.e. +393351234567)
- SMS Answer:** If enabled, 3G Gateway will send a reply SMS after the connection. If disabled, it will activate the connection without sending SMS. The reply SMS is composed by the IP address, get from the network, followed by the text that can be inserted by the side of the check box "sms answer".

CLI activation <input type="checkbox"/>	Phone Num.1 <input type="text"/>
SMS Answer <input checked="" type="checkbox"/>	<input type="text" value="Connessione OK"/>
<input type="button" value="Apply"/>	



Select **Save & Reboot**, press **Commit** and then **Reboot** (Last) to save and make the configuration active.

Commit & Reboot

Save Configuration & Reboot Page

This page allows you to save configuration to flash to retain configuration across reboots. You can also use this page to reboot modem with the configuration file you wanted, simply select the configuration file and press reboot

Commit Configuration

Use to save current Router's configuration to flash

Reboot Router

Use to Reboot Router with the listed configuration files

Reboot From

Last ▾

The Remote Activation functionality can:



1. Enable a remote connection via SMS. The text to be sent to 3G Gateway is "code connect".
2. Enable a remote connection with the CLI identification (Caller ID).
3. Remote reset 3G gateway via SMS (power off - power on). The text to be sent to 3G Gateway is "code reset".



4. Interrupt a connection (Connection option: Manually) via SMS. The text to be sent to 3G Gateway is "code disconnect".



NOTES:

SMS Syntax

The SMS to be sent to 3G Gateway must be composed by: code, blank, text (connect, reset or disconnect) written in small letters.

More activation simultaneously

If while a Remote Activation connection is active, a new connection message comes, 3G Gateway immediately answers to the new request informing about the IP address in use and restarting the "Disconnect timeout".

Reply SMS "NO IP address"

It shows 3G Gateway hasn't got an IP address from the operator. Send connection SMS again. This can occur for temporary problems of connection or for credit exhausted.

5.2.4. DNS




To add a new DNS Relay Server:

- Enter the IP address of the DNS Relay Server in IP Address.
- Click Add.

The page gets refreshed and the IP address of the DNS Relay Server gets listed under IP Address.
You can delete an existing DNS Relay Server by clicking.

Local Network Configuration
DNS Relay

Click Add to add new DNS Relay Server.
Click Delete to delete an existing DNS Relay Server.

IP Address	Delete
208.67.222.222	
208.67.220.220	
Delete All 	

IP Address :

5.3. VOICE CONFIGURATION

Voice Configuration
Voice Configuration
Tel - FXS
Line - FXO
UMTS
FXS Routing Table
UMTS Routing Table
FXO Routing Table
Supplementary Service

In this chapter we refer to two different phone interfaces: FXS and FXO.

FXS interface corresponds to **Tel** connectors of 3G Gateway and it can be connected to a phone or to an analog interface of a PABX (trunk side).

FXO interface corresponds to **LINE** connector of 3G Gateway and it can be connected to a PABX extension or to a public analog line.

The configurations for FXO interface are available only for 3G Gateway models that support this interface.

5.3.1. Voice Configuration

In this page you can configure the general parameters for voice interface.

Voice Configuration

Application:

General

⊕

Activate Mobile Extension

☐

MEx Number

Code for DTMF activation

FXO calls route to:

FXS - DialThru gateway ▾

Integra

⊖

Autocall enable

☐

Phone number

[Advanced Integra Configuration](#)

Apply



NOTE: Integra is a special application implemented for Movistar / Telefonica Spain operator.


5.3.1.1. Mobile Extension – Mex Application

To manage this application, select **Mobile Extension** in the Menu.

The Mobile Extension application is performed by 3G Gateway models supporting both FXO and FXS interface. The installation is performed through the connection of FXO interface on the extensions side of the PABX and of a phone on the FXS interface of 3G Gateway.



Attention: For Mobile Extension configure FXO calls route to: FXS – DialThoru gateway



The **Mobile Extension (MEx)** application allows the diversion of a PABX extension to a mobile phone with the maximum portability. It turns your mobile phone into a PABX extension with the advantage to keep the communication with the PABX, if compared with the traditional call forwarding. For example this permits to forward a call, received on the mobile phone, to an extension during the conversation itself.

To enable the call diversion both to the phone connected to the FXS interface and to the mobile phone (MEx Number), enable the **Activate** option.

The activation will be identified with a special dial tone.

You can enable/disable the Mobile Extension functionality on the phone connected to the FXS interface. The "Code for DTMF Activation" can be set via web interface (default "").

Calls to PABX extension connected to the Gateway (Activate option not enabled)

All the calls addressed to the PABX extension connected to the Gateway (fxo) will be diverted to the phone connected to the FXS interface (Phone 1).

Calls to PABX extension connected to the Gateway (Activate option enabled)

Both the phone connected to the FXS interface (FXS Phone) and the number of mobile phone associated to this functionality (MEx Number) will ring simultaneously when an incoming call arrives to the PABX extension where the FXO interface is connected.

If the communication with MEx Number is enabled, it will be possible to restore the communication with the PABX.

- From MEx Number you will be able to forward the call to a PABX extension.
- Digit "#" on the mobile phone; 3G Gateway will reproduce the flash to the PABX; on the MEx Number it will hear the dial tone and it will be possible to dial a PABX extension (i.e. 101). In the meantime the person of the first call is on hold.
- When 101 extension answers, you will be able to put it in communication with the first person (who is on hold) simply hanging up or pressing "#" again, the on hold call will be enabled.



Note: The "#" character, used as flash button on the mobile phone (MEx Number) can be modified in the (Line – FXO) GSM code for Flash.

Calls to the mobile phone number of the SIM in 3G Gateway

The calls will be managed according to the setting of UMTS Routing Table menu.

Outgoing calls from (Phone 1)

The calls will be managed according to the setting of FXS Routing Table menu.

5.3.1.2. FXO calls route to

With this menu you can configure the redirection of calls received on FXO port to FXS interface (FXS- DialThru gateway) or to GSM/UMTS interface (GSM – FXO gateway).



5.3.2. FXS

Configuration of FXS (Tel) interface.

Line - FXS

Enable CLIR ☒

CLI NONE ▾

Timeout for dialing(s) 4

Pause before dialing(s) 5

Flash detection max (ms) 900

Volume Rx: 7 ▾

Volume Tx: 7 ▾

AutoCall

Enable ☒

Phone number

Timeout(s) 0

Ringing

	Frequency	On	Off	On	Off	On	Off
Ringing Signal	25 ▾	1500	3000	0	0	0	0

Signaling

Reverse polarity ☐

Apply

Tone output

	Frequency	Frequency	On	Off	On	Off	On	Off
Dial Tone	425	0	0	0	0	0	0	0
Busy Tone	425	0	200	200	0	0	0	0
Congestion Tone	425	0	200	200	200	200	200	600

Apply

Default

Enable CLIR (Caller Line ID Restriction)

If CLIR is enabled, 3G Gateway is set not to send its own number (SIM telephone number), the receiver will see “private number”.

CLI (Calling Line Identification)

FSK It enables the display of the caller's telephone number on the display of the telephone connected to the Gateway. The Calling party number is transmitted on FXS port by FSK.

NONE Disable CLI

Timeout for dialing (ms) - Default: 4 sec.

Timeout before starting the call (after the last digit).

Pause before dialing (s) - Default: 5 sec.

Timeout before the automatic dialing of the number insert is UMTS Routing Table (Route to FXS).

Flash detection max (ms)

It indicates the maximum time of line interruption that the device interprets as Flash. A longer time of line interruption is interpreted as a disconnection.

Volume Rx and Tx - Default: 7

Set the volume on FXS port, from 0 (silence) to 10 (high +6db). The step is 2db.

Autocall

Autocall enabled. If after having engaged the 3G Gateway line no number is dialed within the preset Timeout, 3G Gateway will make a call to the number set in "Phone Number" field.

Ringing

It displays the values (frequency and cadence) of the Ring generated on the FXS port. The parameters can be customized.

Signaling

If reverse polarity is enabled, 3G Gateway will change the line polarity to notify the call status.

Tone

It displays the Frequency and Cadence of Dial tone, Busy tone and Congestion tone generated on the FXS port. The parameters can be customized.

To enable double frequency tone insert the value in the second column (blank is disabled).

Default

It reloads the factory settings with the "Tone" values.

5.3.3. FXO

Page for the configuration of FXO (Line) interface.

Line - FXO

Ring before pickup: 1
Flash (generation) (ms): 100
Time out for dialing (s): 4
Outgoing call timeout (s): 180
Volume Rx: 5
Call progress detection: Tones
Ringing frequency: 25

Dialing DTMF
GSM code for Flash #
Volume Tx: 5

Apply

Tone detection

	Frequency	On	Off	On	Off	On	Off
RingBack Tone	340 to 630	1500	3000	0	0	0	0
Busy Tone	340 to 630	200	200	0	0	0	0
Congestion Tone	340 to 630	200	200	200	200	200	600

Apply
Default

Tone output

	Frequency	Frequency	On	Off	On	Off	On	Off
Dial Tone	425	0	0	0	0	0	0	0

Apply
Default

Ring before pickup – Default:1

Define the ring numbers before pickup the line.

Flash (generation - ms): It's the line stop time that 3G Gateway reproduces to its FXO interface (to the PABX) when, in the Mobile Extension application, it receives the DTMF set in **GSM code for Flash**.

Volume Rx and Tx

Set the volume on FXO port, from 0 (silence) to 10 (high +4,5db). The step is 1,5db.

GSM code for Flash (#): It defines the DTMF code that MEX must digit so that 3G Gateway sends a flash to the PABX (FXO) in the Mobile Extension application.

Call progress detection

Tone: 3G gateway checks the Tone parameters (Ringback, Busy and Congestion) in order to define the call status.

Line reversal: 3G Gateway checks the polarity reversal in order to define the call status.

Ringing Frequency:

3G Gateway checks the set ring frequency define the presence of an incoming call.

Tone

It checks the Frequency and Tone Cadence range to define the call status.

5.3.4. UMTS

UMTS

Volume Rx: 4

Volume Tx: 6

Apply

Volume Rx and Tx

Set the volume on UMTS interface, from 0 (silence) to 7(high).

5.3.5. FXS Routing table

Yes

route to GSM

route to GSM

route to FXO

No

With FXS routing table you can decide to forward the numbers dialed on FXS (phone or PBX trunk) to the GSM or to the FXO.
Default is “route to GSM”.

FXS Routing Table						
Prefix	Call enable	Route to	Number of Digits	End with #	Digits to remove	Add string
Default	Yes	route to GSM	0	No	0	

Add

Press **Add** to insert a new rule.

FXS Routing Table Settings

Prefix

Enable

Route to

Number of Digits

End with #

Digits to remove

Add string

Yes

route to GSM

0

No

0

Apply

Cancel

Prefix

Prefix used to identify the rule.

Call Enable

Yes	call allowed
No	call denied

Route to

Route to GSM	the call will be dialed on GSM network
Route to FXO	the call will be dialed on FXO line

Number of Digits

Length of the number to be dialed

0:	No check on length of dialed number
i.e.	Number of digit=3, the rule checks and dials immediately after the 3rd digit

End with

Yes	the call will be dialed immediately after dialing "#"
No	the number will be dialed after the "Timeout for dialing". In this configuration if you insert the "#" in the number, it will be dialed.

Digits to remove

Number of digit to be removed at the beginning of the number.


0	all numbers will be dialed
1	the number will be dialed without the first number (i.e. 0335123456 will be dialed 335123456)

Add string

Number or prefix to be added at the beginning of the number.

Blank	no number will be added
0	the number "0" will be added at the beginning
0039	the prefix "0039" will be added at the beginning

5.3.6. UMTS Routing table



The calls received on the UMTS interface can be rejected or forwarded on the FXS or FXO interface.

Default is “route to FXO”.

UMTS Routing Table		
Incoming Number	Route To	Dial
Default	route to FXS	
<input type="button" value="Add"/>		

Press **Add** to insert a new rule.

Incoming	<input type="text"/>
Route to	route to FXS ▼
Dial	<input type="text"/>
<input type="button" value="Apply"/> <input type="button" value="Cancel"/>	

Incoming

Calling number will be analyzed to apply the rule.

Route to

It defines the calls management: to reject of to forward to FXS or FXO.

Dial

Insert the number to be dialed on FXO or FXS interfaces. If the parameter is blank the caller will hear the Dial Tone.

5.3.7. FXO Routing table

FXO Routing Table IS DISABLED

In order to enable this menu, the parameter FXO calls route to in Voice configuration menu must be set to **GSM – FXO gateway**.



With FXO routing table you can decide to permit (call enable yes) or deny (call enable no) the call according to the prefix number dialed. The call will be dialed through GSM/UMTS module.

FXO Routing Table

Prefix	Call enable	Number of Digits	End with #	Digits to remove	Add string
Default	Yes	0	No	0	

Add

Press **Add** to insert a new rule.

FXO Routing Table Settings

Prefix

Default

Call enable

Yes ▾

Number of Digits

0

End with #

No ▾

Digits to remove

0

Add string

Apply

Cancel

Prefix

Prefix used to indentify the rule.

Call Enable

Yes call allowed
No call denied

Number of Digits

Length of the number to be dialed

0: No check on length of dialed number
i.e. Number of digit=3, the rule checks and dials immediately after the 3rd digit

End with #

Yes the call will be dialed immediately after dialing “#”
No the number will be dialed after the “Timeout for dialing”. In this configuration if you insert the “#” in the number, it will be dialed.

Digits to remove

Number of digit to be removed at the beginning of the number.

0 all numbers will be dialed
1 the number will be dialed without the first number (i.e. 0335123456 will be dialed 335123456)

Add string

Number or prefix to be added at the beginning of the number.

Blank no number will be added
0 the number “0” will be added at the beginning
0039 the prefix “0039” will be added at the beginning

5.3.8. Supplementary services

Supplementary Service

Call waiting ☐

Multiparty service ☐

Apply

Call forwarding	state	error description				
All calls (Unconditionally)	NOT VERIFIED			Enable	Disable	Verify
If busy	NOT VERIFIED			Enable	Disable	Verify
If not answered	NOT VERIFIED			Enable	Disable	Verify
If out of reach	NOT VERIFIED			Enable	Disable	Verify

Call barring	state	error description				
Incoming	NOT VERIFIED			Enable	Disable	Verify
Incoming if roaming	NOT VERIFIED			Enable	Disable	Verify
Outgoing	NOT VERIFIED			Enable	Disable	Verify
Outgoing international	DISABLE			Enable	Disable	Verify
Outgoing international except home	NOT VERIFIED			Enable	Disable	Verify

Call barring password 0000

Apply

Change call barring password

old password

new password

new password

Change

The supplementary services must be supported by the mobile/SIM operator you use in order to be managed.

Call waiting

The Call Waiting service allows to be informed of an incoming call when you are already in a conversation. To answer the incoming call, put on Hold the current conversation by pressing R2 (flash+2). Pressing R2 again you can switch from a conversation to another. To close the current call and take the one on hold, press R1 (flash+1).

Multiparty service

It enables a simultaneous conversation with 2 people. To enable the Multiple Conversation press R3 (flash+3) on the phone connected to 3G Gateway.

Here below the services managed by 3G Gateway (depending on the mobile/SIM operator you use). No WEB configuration menu must be enabled.

HOLD

During a conversation the user can put the call on hold by pressing R (flash) on the phone connected to 3G Gateway. Pressing R again the on hold call will be restored.

ACO, Additional Call Offering

After the conversation (R) has been put on hold, the user will hear the dial tone and will be able to make a second call. With R1, R2 and R3 you will be able to manage to simultaneous calls (see Call waiting and Multiparty service).

3G Gateway manages the supplementary services in two ways, from web page or from DTMF (it will be sufficient to digit some codes from the phone connected to the FXS interface).

In the web page there are some push buttons to Enable, Disable and Verify the state of the service.

Before using the Call Barring you must insert the password used by your mobile operator to manage these services.

Table with DTMF codes used for the supplementary services:

Call Forwarding	Enable	Disable	Verify
Unconditioned (all call)	*21*number# **21*number#	#21# ##21#	*#21#
Busy	*67*number# **67*number#	#67# ##67#	*#67#
No Answer	*61*number# **61*number#	#61# ##61#	*#61#
Out of reach	*62*number# **62*number#	#62# ##62#	*#62#

Call Barring	Enable	Disable	Verify
Incoming Calls	*353*password# *35*password#	#353*password# #35*password#	*#353# *#35#
Incoming if Roaming	*351*password#	#351*password#	*#351#
Outgoing Calls	*333*password# *33*password#	#333*password# #33*password#	*#333# *#33#
Outgoing International Calls	*331*password#	#331*password#	*#331#
Outgoing International call except to home	*332*password#	#332*password#	*#332#

Call Waiting	Enable	Disable	Verify
Call Waiting	*43*	#43#	*#43#

5.4. SYSTEM



5.4.1. Firmware Upgrade

This page displays the current version of the firmware and lets you upgrade to the latest version.

Upgrade

Firmware upgrade
Current firmware version is 10.0.3.23

Automatically Check for Updates
For MyModem to check for updates automatically, ensure your device is connected to the Internet, and then click on the **Check for Updates** button below.

[Check for Updates >](#)

New Firmware File Name:

[Sfoglia...](#)

Warning: DO NOT switch off your Router during firmware upgrades. Please wait for the upgrade to complete before continuing to navigate the configuration manager.

[Upgrade](#)

- Specify the location of firmware file – Click Browse to specify the path where the firmware files are located and click Upgrade.

5.4.2. Backup & Restore

Backup & Restore Configuration

Backup & Restore

Backup Configuration
Use to save the current Router's settings into your computer
Warning: Only configuration saved to Flash will be backed up.

Backup

Restore Configuration
Use to reset your Router with settings previously saved on your computer

Backup file Sfoglia...

Restore

To save the backup configuration file: Click Backup.

A message window opens prompting you to save the file.

- Click Save.
- Specify the path where the file is to be saved and click Save.

To restore the previously saved configuration.

- Click Browse to specify the path of the saved configuration file and click Open.
- Click Upgrade



WARNING: Do not restart your router during configuration restore process.

A message appears indicating the status of restoration:

Configuration Restored

Your FLASH chips have been updated.

Please click [restart](#) to get the new configuration saved.

Read 17722 bytes. Written 17722 bytes

- Click restart to save new configuration.

5.4.3. Commit & Reboot

Follow the steps described under 6.0 Save & Reboot chapter.

5.4.4. User Management

This submenu lets you change the password of user and admin accounts.

Authentication		
User	Comment	
admin	Default admin user	Edit user...
user	Default Gateway user	Edit user...

5.4.5. Time Zone

This submenu lets you configure the SNTP client and server settings. By default, SNTP Client Configuration page opens when you click this submenu.

SNTP Client Configuration

[SNTP Server](#) : **SNTP Client**

SNTP Client Configuration

Set SNTP Clock manually: ☐

YYYY : MM : DD : HH : MM : SS
System Clock : 1970 01 03 00 31 02

TimeZone: UTC(Universal Coordinated)

DayLightSaving: ☐

Mode: Unicast

Retries: 2 (0 - 10 sec)

Timeout: 5 (0 - 30 sec)

PollInterval: 1 (0 - 30 sec)

Apply

Configuring the SNTP Client

To configure the SNTP client:

- Select Set the Clock Manually and specify the time in System Clock in YYYY:MM:DD:HH:MM:SS format.
- Select the Time Zone from the drop down list.
- Specify whether the day light savings applies by selecting Day/Light Savings.
- Specify the Mode by selecting it from the drop down list. The available modes are: None, Unicast, Broadcast, and Anycast.
- Specify the retry time, timeout, and poll interval in Retries, Timeout, and PollInterval respectively. The time range is specified against each of these fields.
- Click Apply.

Configuring the SNTP Server

This submenu lets you add or delete servers.

SNTP Server Settings
 Allows to add a new SNTP Server or delete the existing servers.

Hostname	IP Address	Delete
<div> <input checked="" type="radio"/> Host Name: <input type="text"/> </div> <div> <input type="radio"/> IP Address: <input type="text"/> </div>		
<div>Add</div>		

To configure the SNTP server:

Select one of the options:

- Host Name
- IP Address

Enter the required information and click Add.

5.5. ADVANCED



5.5.1. IGMP Proxy

Configure this proxy to run a server on your local network that can be accessed from the Internet.

IGMP Proxy Configuration
 Enabling the IGMP proxy function will allow the users on your local network to play multimedia which is accessible from the Internet.

Internet Connection <input type="text"/>	IGMP Proxy Enabled <input type="checkbox"/>
<div>Apply</div>	

To enable IGMP proxy:

- Select the connection from Internet Connection drop down list.
- Select IGMP Proxy Enabled.
- Click Apply.

5.5.2. IP Routing

You can configure IP routing by:

- Static Routing
- Dynamic Routing

Static Routing

IP Routing Configuration

Static Routing | [Dynamic Routing](#)

IP Static Route Settings

Current routes:

Destination	Netmask	Gateway	WAN Interface	Delete
<div>Add</div>				

- To set static routing: Click Add.

Add New Static Route page opens.

Static Routing | [Dynamic Routing](#)

Add New Static Route

Destination For default route, type 0.0.0.0 or leave blank

IP Address

Netmask

Forward packets to

☐ Gateway IP address:

☒ Interface:

Apply

- Enter the destination IP Address and Netmask.
- Enter the Gateway IP Address and Interface, where the packets are to be forwarded.
- Click Apply.

Dynamic Routing

IP Routing Configuration

[Static Routing](#) | **Dynamic Routing**

IP Dynamic Routing Settings

You can enable the function on several interfaces of your Router. Select the desired RIP version and operation mode, then tick the 'Enabled' checkbox to enable RIP.

Interface	RIP Version	Operation Mode	Enabled	Edit
ip0	N/A	N/A	<input checked="" type="checkbox"/>	

To enable the dynamic routing:

- Click Edit.
- Select the RIP Version as 1, 2 or both.
- Select the Operation Mode as Active, Passive, or Send Only.
- Select Enabled.
- Click Apply.

5.5.3. Dynamic DNS

Dynamic DNS Configuration

Dynamic DNS

This page allows you to provide Internet users with a domain name (instead of an IP address) to access your virtual servers. Your Router supports dynamic DNS service provided by the provider 'http://www.dyndns.org' or 'http://www.tzo.com'. Please register this service at these providers first *.

Dynamic DNS:

Dynamic DNS Provider:

User Name:

Password:

Email:

Key:

Wildcard:

Domain Name:

☒ Disable ☐ Enable

DynDNS.org

☒ Disable ☐ Enable

* Please note that Digicom is not linked in any way with any Dynamic DNS service providers. Therefore Digicom cannot guarantee the level of service or support offered by your chosen service provider.

Apply

To enable the dynamic DNS:

- Click to select Enabled for Dynamic DNS.
- Specify the Internet Connection, User Name, Password, Email, Key, Wildcard, Domain Name, and Status.
- Click Apply.

5.5.4. UPnP

UPnP Configuration

UPnP Settings

Enable UPnP to help support applications that would not otherwise work behind a Router. Both UPnP Internet Gateway Device and NAT Traversal are supported.

Enable UPnP ☐

UPnP port

In this menu you can enable/disable the Universal Plug and Play (UPnP).
Default: disabled

5.5.5. Remote Configuration

In this menu you set the TCP port through which 3G Gateway is configured. The default port is 80 (standard for all browsers). In case, mainly for the remote configuration, the 80 port is busy for other services you can modify 3G Gateway configuration port. If you use configuration ports different from 80 you must specify them in the address (example: for 8000 port the configuration address will be <http://192.168.1.254:8000/>).

Web

Http_Port:

Management Ip address:

Management subnet mask:

Management Ip address(2):

Management subnet mask(2):

CSD

Enable maintenance calls: ☒

Phone number 1

Phone number 2

Phone number 3

Phone number 4

Phone number 5

CSD

It allows to answer and to accept modem calls (i.e., 9600bps in V.32) to remote configure the voice functionalities through Windows utility.



NOTE: This application is supported for telecom operators or special projects only.

5.5.6. Half Bridge

Attention: this function is not supported.

5.5.7. Auto ping

Auto ping

Enable auto ping:

☐

Destination:

Repeat:

Period (s):

Apply

It enables the auto ping function by 3G Gateway to a certain IP address. 3G Gateway will generate the PING starting from its LAN interface.

Destination	Client to which the PING must be performed
Repeat	Number of PING requests to be performed
Period (s)	It defines the timer for the PING

Auto ping

Enable auto ping:

☒

Destination:

Repeat:

Period (s):

Apply

With this configuration 3G Gateway will perform **5 pings** every **60 seconds** to 192.168.4.2 address.



NOTE: this function allows to enable and keep active an IPSEC VPN connection when for the performed configuration it is necessary that the request starts from 3G Gateway.

5.6. FIREWALL



5.6.1. IP Filtering

To specify the IP filter settings:

Enable/disable the IP filter by selecting Enabled/Disabled. Click Apply.

Port Filters

Edit or delete the port filters by clicking Edit or Delete.

IP Filters

To add an IP filter:

- Click Add.

Add New Outbound IP Filtering page opens:

IP Filter

Add New Outbound IP Filtering Rule

Filter Rule Name:

Select policy:

ext-int

Select the direction to filter packets:

☒ Outbound traffic

☐ Inbound traffic

☐ Both

☒ **Port Filter Rule**

Protocol:

TCP

Source IP Range:

Start

End

Source Port Range:

Start

End

Status:

☐ Enabled

☐ Disabled

☐ **IP Validator Rule**

IP address:

SINGLE

IP address:

Netmask:

Status:

☐ Enabled

☐ Disabled

Apply

- Enter the name of filter rule in Filter Rule Name.
- Select the filter policy from the Select Policy drop down list.
- Select one of the option for the direction of filter packets: Outbound traffic, Inbound traffic, Both
- Specify the Port Filter Rule by specifying the Protocol, Source IP Range, Source Port Range, and Status (Enabled/ Disabled).

- Specify the IP Validator Rule by specifying the IP Address type (Single, Subnet), IP Address, Netmask, and Status (Enabled/Disabled).
- Click Apply.

5.6.2. Domain Filtering

Domain Filter Settings

This page allows you to specify the Domain filter rules to prevent access or allow from the specified configured list of sites, so as to limit the Internet access for computers on your network based upon the Domain's.

Rule Action:					
<input type="radio"/> Allow <input checked="" type="radio"/> Deny					
<input type="button" value="Apply"/>					
Filter Name	Policy Name	Domain Filter	Start Time	End Time	Delete
Filter Name	Policy Name	Domain Filter	Start Time (hh:mm:ss)	End Time (hh:mm:ss)	
<input type="text"/>	ext-int ▼	<input type="text"/>	<input type="text"/> : <input type="text"/> : <input type="text"/>	<input type="text"/> : <input type="text"/> : <input type="text"/>	
<input type="button" value="Add"/>					

To specify domain filter settings:

- Specify the rule action as Allow or Deny and click Apply.
- Enter the filter details such as Filter Name, Policy Name, Domain Filter, Start Time (hh:mm:ss), End Time (hh:mm:ss).
- Click Add.

5.6.3. Intrusion detection

Intrusion Detection Configuration

Use Blacklist	<input type="text" value="false"/>
Victim Protection Block Duration	<input type="text" value="600"/> seconds
Scan Attack Block Duration	<input type="text" value="86400"/> seconds
DOS Attack Block Duration	<input type="text" value="1800"/> seconds
Maximum TCP Open Handshaking Count	<input type="text" value="5"/> per second
Maximum Ping Count	<input type="text" value="15"/> per second
Maximum ICMP Count	<input type="text" value="100"/> per second

5.7. VIRTUAL SERVER

Virtual Server
Virtual server
DMZ

5.7.1. Virtual server

Virtual server Configuration

Virtual server Settings

This page allows to create, modify and delete port forwarding rules. These rules allow applications or software to work on your computers if the Internet connection uses NAT.

Name	Protocol	External Port	Internal IP	Internal Port	Edit	Delete
<div>Add</div>						

Port Forwarding

Add New Port Forwarding Rule

Name:

☒ Pre-defined: Audio/Video Cameras

☐ User defined:

WAN Interface :

Forward to Internal Host IP Address:

By using the rules:

Protocol/Type	External Packet		Forward to Internal Host	
	Port Start	Port End	Port Start	Port End
None				
None				
None				

Apply

5.7.2. DMZ

DMZ Configuration

DMZ Host

A DMZ host is a computer on your local network that can be accessed from the Internet.

Interface	DMZ Host	Edit

A DMZ (DeMilitarized Zone) host is a computer on your network that can be accessed from the Internet regardless of NAT, port forwarding and IP filter settings. A DMZ is often used to host Web servers, FTP servers etc that need to be accessible from the Internet.

Setting up a DMZ has implications on the security of your network. Set-up a DMZ only if you understand the consequences. **Port forwarding settings will override your DMZ setting.**


To setup a DMZ Host:

- Select the WAN interface and click Edit.
- Select Forwarded to the DMZ Host
- Enter the IP address of the computer you wish to place in the DMZ
- Click Apply.

5.8. SMS

This menu allow you to read and send SMS directly from 3G Gateway.

5.9. SECURITY



5.9.1. Backup

Backup

BackUp

Send SMS ☐ N°1 N°2

Apply

Backup

By setting this menu in **ADSL+back-up 3G** or **3G+back-up ADSL** applications 3G Gateway will send an SMS (up to two addressees) to inform when the device makes the backup/restore. The SMS will contain the public IP address received by the network.

5.9.2. In Out

This function is supported by **3G Corporate** through the 7 PIN screwless terminal board that has a relay output with COM – NA – NC contacts and an optoinsulated bidirectional input with 12V pull-up. Maximum range 2A at 150V.

Description of 7 PIN terminal board

- 1 COM relay output
- 2 N.O. relay output
- 3 N.C. relay output
- 4 GND ground
- 5 Optoinsulated input
- 6 Optoinsulated input
- 7 +12Vcc

The contacts (IN and OUT) management is performed through the **"In Out"** web configuration page in the **Security** menu.

In/Out

Status

Update

IN open

OUT open

Input

Stand by ☐

Default

Open ☒

Closed ☐

Data Connection

From default to new ☐

From new to default ☐

Send SMS

From default to new ☐

From new to default ☐

Text +IP ☐

Text +IP ☐

SMS Number

N1

N2

Output

Open ☒

Close ☐

Reset

Reset time (s)

Apply

The configuration page is divided into three parts: Status, Input and Output.

Status

By pressing "Update" the input and output status will be tested and displayed.

Input

- Stand by** It defines if it applies or not the rules defined in this configuration page. It enables/disable this option. It enables as soon as "Apply" is selected.
- Default** To save the desired setting you must choose "Commit" in the Save & Reboot menu. It allows to configure the default input status.

At an input status change it will be possible to define the actions to be enabled: Data Connection and/or Send SMS.

Two possible situations are defined:

- 1) The input moves from the default status (Open/Close) to a new one (opposite situation to default)
- 2) It restores the default status.

- Data Connection** It defines after which input status change a data connection must be enabled. For the 3G connection it will be used the "Disconnect timeout (s)" present in the **Remote Activation** menu (Configuration\WAN\3G UMTS). See also **Security\Disconnect timeout**.
- Send SMS** It defines after which input status change it must send an SMS to communicate the event. In the Text field you define the message to be sent and by selecting the "+IP" item, the public IP address of 3G Gateway will be automatically added in the message. This option is useful in case the Internet network (3G/ADSL) assigns a dynamic IP address.
- SMS Number** It allows the configuration of at least two phone numbers to which the notification SMS of status change is sent. (Send SMS configuration).

Output

It allows to modify the output status. The factory default is Open. To close the output you must select Close and confirm with Apply (the status change will be immediate). If you want the new status (i.e. Close) is used as default value by 3G Gateway (to be kept also in case the device is powered off and on again) choose "Commit" in the Save & Reboot menu.

- Reset** By pressing Reset you will perform a status change for the time set in Reset time (s).

5.9.3. E-Mail

E-Mail			
Check E-Mail received <input type="checkbox"/>	Port <input type="text" value="25"/>		
Forward to SMTP server <input type="checkbox"/>	Host <input type="text"/>	Port <input type="text" value="25"/>	
Data connection <input type="checkbox"/>			
Send SMS <input type="checkbox"/>	Text <input type="text"/>	+ IP <input type="checkbox"/>	
SMS Number	N1 <input type="text"/>	N2 <input type="text"/>	
<input type="button" value="Apply"/>			

The network devices (IP Cameras, Routers, PLC, etc.) that can be set to send e-mails after certain events are more an more popular. You can set 3G Gateway to intercept and manage these e-mails in case the SMTP Server set in the message is the LAN address of 3G Gateway.

Check received E-mail It defines if 3G Gateway must examine the eventual received e-mails (e-mails with LAN IP address of 3G Gateway as SMTP Server) and on which TCP port it must check (Port).

Forward to SMTP server It defines if it must forward the received e-mails to a different SMTP server. Set Host and Port. 3G Gateway manages one e-mail message at a time and it can forward message with attachments not higher than 100KB.

After an e-mail is received it will be possible to define the actions to be performed: Data Connection and/or Send SMS.

Data Connection It defines if a data connection must be activated after an e-mail has been received. For the 3G connection the "Disconnect timeout (s)" in the Remote Activation menu (Configuration\WAN\3G UMTS) will be used. See also Security\ Disconnect timeout menu.

Send SMS It defines if an SMS must be sent after an e-mail has been received to communicate the event. In the Text filed you will be able to define the message to be sent and by selecting the "+IP" item, the public IP address of 3G Gateway will be automatically added in the message. This option is useful in case the Internet network (3G/ADSL) assigns a dynamic IP address.

SMS Number It allows the configuration of at least two phone numbers to which the notification SMS of status change is sent. (Send SMS configuration).

5.9.4. Disconnect timeout

Disconnect Time-out	
Disconnect time-out	
Timer status	Disconnect timer not active
Set to value	<input type="text" value="3600"/> <input type="button" value="Set"/> <input type="button" value="Disable"/>

[Go to Connect/Disconnect page \(Home\)](#)

Through this menu it is possible to modify during a 3G data connection the value of the "Disconnect timeout (s)" set in the **Remote Activation** menu.

In manual connection configuration (Configuration\ **WAN\ 3G UMTS**\ Connection\ Manually) 3G Gateway can enable 3G UMTS data connections after certain events occur:

- SMS reception (Configuration\ WAN\ 3G UMTS\ Remote Activation)
- Reception of a phone ring (Configuration\ WAN\ 3G UMTS\ Remote Activation)
- At e-mail reception from devices on the LAN interface (Configuration\Security\E-Mail)
- At digital input status change on model 3G Corporate (Configuration\Security\ In Out)

<div> <div>Wan</div> <div>WAN configuration</div> <div>Internet Configuration</div> <div>3G Umts</div> <div>DNS</div> <div>Voice Configuration</div> <div>System</div> </div>	<h3>Advanced 3G Configuration</h3> <table> <tr> <td>Network mode</td> <td>Automatic ▾</td> </tr> <tr> <td>Connection</td> <td>Manually ▾</td> </tr> <tr> <td>SMS service centre</td> <td><input type="text"/></td> </tr> </table>	Network mode	Automatic ▾	Connection	Manually ▾	SMS service centre	<input type="text"/>
Network mode	Automatic ▾						
Connection	Manually ▾						
SMS service centre	<input type="text"/>						

The connections time is defined in the "Disconnect timeout (s)" parameter in the Remote Activation menu.

Remote Activation <input checked="" type="checkbox"/>	
Code <input type="text" value="1111"/>	Anyone <input checked="" type="checkbox"/>
Delete all SMS <input checked="" type="checkbox"/>	Disconnect timeout (s) <input type="text" value="600"/>
CLI activation <input type="checkbox"/>	Phone Num.1 <input type="text"/>
SMS Answer <input type="checkbox"/>	<input type="text"/>

If during the data connection you need to modify the Disconnect timeout (s) or to disable it (for example if in an alarm situation you are controlling a remote IP Camera) you will be able to intervene using the options in the menu.

Timer Status	It displays the time to disconnection.
Set Value	It defines the time to be set as "Disconnect timeout" for the current connection. After the value has been inserted (seconds), press "Set" to enable it.
Disable	It disables the "Disconnect timeout" for the current connection.

ATTENTION: to stop the connection press "Disconnect" in the Home configuration page.



NOTE: The actions that you can enable in the "Configuration\Security\Disconnect timeout" configuration menu will be valid only for the current connection and will not modify the "Disconnect timeout (s)" value set in the Remote Activation menu.

6. SAVE & REBOOT

6

Commit & Reboot

Save Configuration & Reboot Page

This page allows you to save configuration to flash to retain configuration across reboots. You can also use this page to reboot modem with the configuration file you wanted, simply select the configuration file and press reboot.

Commit Configuration

Use to save current Router's configuration to flash

Commit

Reboot Router

Use to Reboot Router with the listed configuration files

Reboot From

Last ▾

Reboot

This submenu lets you reboot the modem. You can reboot from the following configurations:

Last Configuration

Factory Configuration

To reboot the modem:

Select Reboot From as Last or Factory.

Click Reboot.

A message appears displaying the status of rebooting:

Please wait for 1 minute to let the system reboot.
Rebooting System...

A page displaying the overview of device information opens.

7. LOGOUT

This menu allow you to logout from the web configuration.



Italy 21010 Cardano al Campo VA
via Alessandro Volta 39
<http://www.digicom.it>

