




**SNM31**  
**SNM31F**  
*(VFAST APPENDIX)*

**OPERATION MANUAL**





**SNM31**  
**SNM31F**  
*(VFAST APPENDIST)*  
**OPERATION MANUAL**

*All rights reserved; no part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, otherwise, without the prior written permission of the publishers.*

*The contents of this booklet may be modified without prior permission.*

*Every possible care has been taken in testing and putting together all the documentation contained in this booklet, however DIGICOM can not take any responsibility brought by the use of this booklet.*

## INDEX

<b>ATTENTION !</b>	<b>I</b>
<b>PRECAUTIONS</b>	<b>II</b>
<b>PREFACE</b>	<b>IV</b>
<b>1. GENERAL</b>	<b>1.1</b>
1.1. FUNCTIONAL CHARACTERISTICS	1.1
<b>2. PHYSICAL DESCRIPTION</b>	<b>2.1</b>
2.1. LED DEFINITION	2.1
2.2. POWER UP SELF-TEST	2.2
<b>3. FRONT PANEL OPERATION</b>	<b>3.1</b>
3.1. STORING NUMBER IN MEMORY	3.4
3.2. USING NUMBERS IN MEMORY	3.4
3.2.1. Indirect Dialling 0 to 19 Locations	3.5
3.2.2. Direct Dialling 0 to 3 Locations	3.5
<b>4. AT COMMANDS</b>	<b>4.1</b>
4.1. COMMAND BUFFER	4.2
4.2. AUTO-BAUD AND AUTO-PARITY DETECTION	4.2
4.2.1. Data Length	4.3
<b>5. AT COMMAND SET</b>	<b>5.1</b>
5.1. AT COMMAND SUMMARY	5.1
<b>6. AT COMMAND SET DESCRIPTION</b>	<b>6.1</b>
6.1. DIAL COMMANDS (ATD)	6.31
6.2. ADDITIONAL COMMANDS USED WITH AT&Z	6.33
<b>7. V.25bis COMMANDS</b>	<b>7.1</b>
7.1. ASYNCHRONOUS V.25BIS COMMANDS	7.1
7.2. ASYNCHRONOUS V.25BIS COMMAND SET	7.2
7.3. ASYNCHRONOUS V.25BIS INDICATIONS	7.6
7.4. SYNCHRONOUS V.25BIS	7.9
7.5. SYNCHRONOUS V.25BIS COMMANDS	7.10
7.6. SYNCHRONOUS V.25BIS RESPONSES	7.10
7.7. V.25BIS COMMAND AND RESPONSE SUMMARY	7.11
<b>8. USEFUL NOTES</b>	<b>8.1</b>
8.1. DIALLING STORED NUMBER	8.1
8.2. MANUAL CALL ORIGINATION	8.2
8.3. AUTOMATIC ANSWER	8.2
8.4. MANUAL ANSWER	8.3
8.5. AUTOMATIC SPEED DETECTION	8.3
8.6. DISCONNECTING A CALL	8.3
8.7. DISCONNECTION FOR LOSS OF DTR	8.4
8.8. DISCONNECTION FOR LOSS OF CARRIER	8.4
8.9. DISCONNECTION THROUGH MEMBRANE SWITCH	8.4
8.10. DISCONNECTION FOR POOR SIGNAL QUALITY	8.4
8.11. MODE SELECTION	8.5

8.12.	CLOCK SELECTION	8.5
8.14.	LEASED LINE OPERATION	8.6
8.14.1.	Installation of 2-wire connections	8.6
8.14.2.	Operation on 2-wires	8.6
8.14.3.	Automatic Dial Line Back-up	8.7
8.14.4.	Back-up with More Telephone Numbers	8.8
8.14.5.	Back-up Sequence Procedure	8.8
8.14.6.	Different configuration set by the Originate modem	8.9
8.14.7.	Different configuration set by the Answer modem	8.10
8.14.8.	Automatic Leased Line Lookback	8.12
8.15.	SIGNAL QUALITY ACTION	8.12
8.15.1.	Understanding Signal Quality	8.12
8.16.	CALL-BACK SECURITY	8.14
8.16.1.	Function Description	8.14
8.16.2.	Extended Call-Back	8.15
<b>9.</b>	<b>REMOTE CONFIGURATION</b>	<b>9.1</b>
9.1.	REMOTE CONFIGURATION FROM DTE	9.2
9.2.	DOWN-LOAD FROM FRONT PANEL	9.3
9.3.	DOWN-LOAD FROM DTE	9.3
<b>10.</b>	<b>COMMAND PORT AND MAIN PORT</b>	<b>10.1</b>
<b>11.</b>	<b>S-REGISTERS</b>	<b>11.1</b>
11.1.	S-REGISTER DESCRIPTION	11.4
<b>12.</b>	<b>RESET AT POWER UP</b>	<b>12.1</b>

## APPENDIX INDEX

<b>Appendix A.</b>	<b>V.24 MAIN PORT CIRCUITS</b>	<b>A.1</b>
<b>Appendix B.</b>	<b>V.24 COMMAND PORT CIRCUITS</b>	<b>B.1</b>
<b>Appendix C.</b>	<b>CABLE CR 3</b>	<b>C.1</b>
<b>Appendix D.</b>	<b>CABLE CR 24</b>	<b>D.1</b>
<b>Appendix E.</b>	<b>EXTERNAL INTERCONNECTIONS</b>	<b>E.1</b>
<b>Appendix F.</b>	<b>TRANSMISSION LEVELS</b>	<b>F.1</b>
<b>Appendix G.</b>	<b>JUMPER SETTING</b>	<b>G.1</b>
<b>Appendix H.</b>	<b>LOOP DESCRIPTION</b>	<b>H.1</b>
<b>Appendix I.</b>	<b>REMOTE CONFIGURATION</b>	<b>I.1</b>
<b>Appendix J.</b>	<b>FUNCTION OF A LEASED LINE AND BACK-UP</b>	<b>J.1</b>
<b>Appendix K.</b>	<b>TECNICAL CHARACTERISTICS</b>	<b>K.1</b>
K.1.	ELECTRICAL CHARACTERISTICS AND INTERFACE	K.1
K.2.	TRANSCIEVER AND RECEIVER	K.2
K.3.	AUTO ANSWER	K.3
K.4.	AUTOMATIC CALL	K.4
<b>Appendix L.</b>	<b>DEFAULT CONFIGURATION</b>	<b>L.1</b>
L.1.	CONFIGURATION #0	L.1
L.2.	CONFIGURATION #1	L.2
L.3.	CONFIGURATION #2	L.2

L.4.	CONFIGURATION #3	L.3
L.5.	CONFIGURATION #4	L.3
L.6.	CONFIGURATION #5	L.4
L.7.	CONFIGURATION #6	L.5
L.8.	CONFIGURATION #7	L.6
L.9.	CONFIGURATION #8	L.7
L.10.	CONFIGURATION #9	L.8
<b>Appendix M.</b>	<b>VFAST FUNCTIONALITY</b>	<b>M.1</b>
M.1.	SPECIAL VFAST FUNCTION	M.3
<b>Appendix N.</b>	<b>COMMAND AND REGISTER DESCRIPTION</b>	<b>N.1</b>

## APPENDIX FIGURE

Fig.:1.	SNM31 Front Panel	3.1
Fig.:2	CABLE CR 3	C.1
Fig.:3	CABLE CR24	D.1
Fig.:4	DIP-SWITCH FOR SWITCHED LINE	E.1
Fig.:5	DIP-SWITCH FOR SWITCHED LINE	F.1
Fig.:6	DIP-SWITCH FOR LEASED LINE	F.2
Fig.:7.	JUMPER SETTING	G.1
Fig.:8.	LOOP DESCRIPTION	I
Fig.:9.	REMOTE CONFIGURATION	I.1
Fig.:10.	FUNCTION OF A LEASED LINE WITH NO BACK-UP	J.1
Fig.:11.	FUNCTION OF A LEASED LINE WITH ACTIVE BACK-UP	J.3
Fig.:12.	BACK-UP WITH C116	J.5

## APPENDIX TABLE

Tab.:1.	Modulation Standard	1.2
Tab.:2.	C105/C106 Delay time	1.4
Tab.:3.	Modulation Standard Format	6.3
Tab.:4.	Extended result codes	6.7
Tab.:5.	Signal Quality Action	8.13
Tab.:6.	Address V54	11.37
Tab.:7.	MAIN PORT INTERFACE CIRCUITS	A.1
Tab.:8.	COMMAND PORT INTERFACE CIRCUITS	B.1
Tab.:9.		M.1
Tab.:10.		M.2



**Registered and Head Office**

21010 Cardano al Campo VA - via A. Volta 39 Tel. 0331/263122 Fax 0331/263733

**Head Office Roma**

00145 Roma - via Cristoforo Colombo 436

Tel. 06/5416206 - Fax 5412828

**Head Office Bologna**

40122 Bologna - via Lame 116 -Tel. 051/558709-558140

**Head Office Firenze**

50134 Firenze - via Cesalpino 7 - Tel. 055/4360373-4221202

**Head Office Torino**

10129 Torino C.so De Gasperi 26 Tel. 011/504802 FAX 011/504627

**Head Office Padova**

35030 Rubano PD Via della Provvidenza 37 Tel. 049/8976528

FAX 049/8976524

